

Cortek srl

Cortek Happy Mechanical Keyboard Fast Manual

Thanks for your purchase of our product. This product is built in accordance with the regulations of the European Community and follows CE and RoHS directives.
For features and specifications you can refer to www.cortek.it

Manuale rapido per tastiera meccanica Cortek Happy

Grazie per aver acquistato questo prodotto. Questo prodotto e' stato costruito seguendo le regole della comunita' europea e le direttive CE and RoHS.
Troverai caratteristiche e specifiche anche su : www.cortek.it



General informations

The Happy keyboard is a high quality product. It is a hot swap mechanical keyboard with 68 keys, communication is Bluetooth, RF or wired. The switches mounted are the Cortek Phantom Silent Linear (code HAPPYS) or the Kailh Box White Click-bar (code HAPPYC).

The version with the Cortek Silent switches and the two absorbent internal layers give a particularly soft and pleasant touch. The version with the Kailh Box White switches is for click lovers, as it is well known that the best click on the market is precisely that of the switches

Kailh Box in the various versions, this "Click-Bar" technology being superior to the others.

Happy is equipped with a volume setting knob and RGB lighting which is also on the side and at the bottom. The keys are colored (3 colours) and, in addition to the US layout, have Italian characters printed on the front. Happy is equipped with software that can be downloaded from the Cortek website.

The package includes a transparent keyboard cover and an extractor for keys and switches.

Commands

FN+1..0 = F1..F10, FN+- = F11, FN+= = F12, FN+BACKSPACE = DEL,
FN+`~ = ESC, FN+1 = Music, FN+2 = -volume, FN+3 = +volume, FN+4 = mute,
FN+5 = pause, FN+6 = prev. track, FN+7 = play/pause, FN+8 = next track, FN+9 = email,
FN+0 = home page, FN+_ - = My computer, FN+= calculator, FN+↑ = +brightness,
FN+↓ = - brightness, FN+← = -speed, FN+ → = +speed, FN+| = 22 effects,
FN+L = 11 effects, FN+TAB = backlight color, FN+DEL = INS, FN+PageUp = HOME,
FN+PageDown = END, FN+[{ = PRTSC, FN+]} = SCRLK, FN+” = PAUSE, FN+Z = Win,
FN+X = Mac, FN+Spacebar = reset, FN+W = switch cursors.

Wheel: Press down to adjust the side light effect, rotate left and right to adjust the brightness of the side light.

Press and hold for 3 seconds to change function. Press down to mute, rotate the knob left and right to adjust the volume, when switching functions, the big and small lights flash three times to indicate.

Connessioni

FN+E = for BlueTooth1, FN+R = for BlueTooth2, FN+T = for BlueTooth3

Short press to switch to Bluetooth channel 1/2/3. Press and hold for 3 seconds to delete pairing information and start a new transmission. When disconnected, the indicator light flashes and stops flashing after connection.

FN+Q = for 2.4Ghz

You need to use the 2.4G wireless receiver dongle. Short press to switch to 2.4G channel.

Press and hold for 3 seconds to enter pairing mode again. When disconnected, the indicator light flashes and stops flashing after connection.

FN+Y = for USB cable

Informazioni generiche

La tastiera Happy e' un prodotto di alta qualita'. Si tratta di una tastiera meccanica hot swap con 68 tasti, la comunicazione e' Bluetooth, RF o con cavo. Gli switch montati sono i Cortek Phantom Silent Linear (codice HAPPYS) o i Kailh Box White Click-bar (codice HAPPYC).

La versione con gli switch Cortek Silent e i due strati interni assorbenti danno un tocco particolarmente morbido e piacevole. La versione con gli switch Kailh Box White e' per gli amanti del click, come e' risaputo il click migliore del mercato e' appunto quello degli switch Kailh Box nelle varie versioni, essendo questa tecnologia "Click-Bar" superiore alle altre.

Happy e' dotata di una rotella per settaggio volume e illuminazione RGB che e' anche di lato e nella parte inferiore. I tasti sono colorati (3 colori) e, oltre al layout USA, hanno frontalmente stampati i caratteri italiani. Happy e' provvista di software scaricabile dal sito Cortek.

Nella confezione si trovano inclusi un copritastiera trasparente e un estrattore per tasti e switch.

Comandi

FN+1..0 = F1..F10, FN+- = F11, FN+= = F12, FN+BACKSPACE = DEL,
FN+`~ = ESC, FN+1 = Music, FN+2 = -volume, FN+3 = +volume, FN+4 = mute,
FN+5 = pause, FN+6 = prev. track, FN+7 = play/pause, FN+8 = next track, FN+9 = email,
FN+0 = home page, FN+_ - = My computer, FN+= calculator, FN+↑ = +brightness,
FN+↓ = - brightness, FN+← = -speed, FN+ → = +speed, FN+| = 22 effects,
FN+L = 11 effects, FN+TAB = backlight color, FN+DEL = INS, FN+PageUp = HOME,
FN+PageDown = END, FN+[{ = PRTSC, FN+]} = SCRLK, FN+” = PAUSE, FN+Z = Win,
FN+X = Mac, FN+Spacebar = reset, FN+W = switch cursori.

Rotella : premere verso il basso per regolare l'effetto della luce laterale, ruotare a sinistra e a destra per regolare la luminosità della luce laterale.

Tenere premuto per 3 secondi per cambiare funzione. Premere verso il basso per disattivare l'audio, ruotare la manopola a sinistra e a destra per regolare il volume, quando si cambiano le funzioni, le luci grande e piccola lampeggiano tre volte per indicare.

Connessioni

FN+E = per BlueTooth1, FN+R = per BlueTooth2, FN+T = per BlueTooth3

Premere brevemente per passare al canale Bluetooth 1/2/3. Tenere premuto per 3 secondi per eliminare le informazioni di associazione e avviare una nuova trasmissione. Quando disconnesso, l'indicatore luminoso lampeggia e smette di lampeggiare dopo la connessione.

FN+Q = per 2.4Ghz

E' necessario utilizzare il dongle del ricevitore wireless 2.4G. Premere brevemente per passare al canale 2.4G. Tenere premuto per 3 secondi per accedere nuovamente alla modalità di associazione. Quando disconnesso, l'indicatore luminoso lampeggia e smette di lampeggiare dopo la connessione.

FN+Y = per cavo USB