

Cortek srl

Gammec XSniper Keyboard Fast Manual

Thanks for your purchase of our product. This product is builded in accordance with the regulations of the European Community and follows CE and RoHS directives.
For features and specifications you can refer to www.cortek.eu, www.gammec.com.

Manuale rapido per tastiera Gammec XSniper

Grazie per aver acquistato questo prodotto. Questo prodotto e' stato costruito seguendo le regole della comunita' europea e le direttive CE and RoHS.
Troverai caratteristiche e specifiche anche su : www.cortek.eu, www.gammec.com.



Generic informations

The Gammec XSniper is a keyboard with suspension keys, with backlight in 3 different selectable rainbow colors and with some gaming functions. The keyboard has ITALIAN layout. The keyboard uses USB connection and is usable with all the more popular operating systems. Being the keys suspended the internal components are well protected against external agent. The circuits are optimized to minimize conflicts between the keys even if pressed simultaneously (Anti-Ghost).

Illumination

The XSniper is equipped with backlight in 3 different selectable rainbow colors. It is a backlight of the entire base of the keyboard and also the letters are illuminated being the keys drilled by laser.

To set the various colors of the lighting must simultaneously press the FN key and the BI/Sc, this allows to move sequentially from one rainbow color to another and also allows you to completely turn off the light.

The intensity of the light can be adjusted on 3 levels plus a level off by simultaneously pressing the FN+PgUp and FN+PgDn.

A respiration animation will be activate pressing the FN+Pause, pressing again will be back to the standard mode.

Gaming Functions

The GK1 is with gaming functions can be activated by pressing the FN key and some other keys :

FN+Q : you can set two different keys repeat speed.

FN+W : exchange in hardware WASD with the ARROW keys.

FN+WIN (button on the left of the left ALT key) : locks the Windows keys.

Windows e Multimedia Functions

The keyboard is equipped with Windows and Media functions that can be activated by pressing the FN key and the 12 functions keys F1..F12.

FN+F1..F8 : 8 Audio/Video Functions.

FN+F9 : Internet.

FN+F10 : Mail.

FN+F11 : Computer.

FN+F12 : Lock/Unlock.

Informazioni generiche

La Gammec XSniper e' una tastiera a tasti sospesi, con retroilluminazione in 3 diversi arcobaleno a scelta e con funzioni gaming. La tastiera ha layout ITALIANO.

La tastiera usa la porta USB e funziona con tutti i principali sistemi operativi.

Essendo i tasti in sospensione i circuiti interni sono ben protetti contro eventuali agenti esterni. I circuiti sono ottimizzati per ridurre al minimo i conflitti tra i tasti anche se pigiati contemporaneamente (Anti-Ghost).

Illuminazione

La tastiera e' dotata di retro illuminazione in 3 diversi arcobaleno selezionabili.

Si tratta di retroilluminazione di tutta la base della tastiera e inoltre le lettere sono illuminate essendo i tasti perforati al laser.

Per settare i vari colori di illuminazione bisogna premere contemporaneamente il tasto FN e il tasto BI/Sc, questo permette appunto di passare in sequenza da un colore arcobaleno all'altro e inoltre permette di spegnere totalmente l'illuminazione.

L'intensita' dell'illuminazione puo' essere regolata su tre livelli + un livello di spento premendo contemporaneamente i tasti FN+PagSU e FN+PagGIU.

Un' animazione di respiration e' disponibile premendo FN + il tasto Pausa, ripremendo si torna in modalita' standard.

Funzioni Gaming

La tastiera e' dotata di funzioni gaming attivabili premendo contemporaneamente il tasto FN e alcuni altri tasti:

FN+Q : e' possibile settare due diverse velocita' di ripetizione tasti.

FN+W : scambia a livello hardware i tasti WASD con i tasti CURSORE.

FN+WIN (tasto a sinistra del tasto ALT sinistro) : blocca i tasti Windows.

Funzioni Windows e Multimediali

La tastiera e' dotata di funzioni Windows e Multimediali attivabili premendo contemporaneamente il tasto FN e i 12 tasti funzione da F1 a F12.

FN+F1..F8 : 8 Funzioni Audio/Video.

FN+F9 : Internet.

FN+F10 : Mail.

FN+F11 : Computer.

FN+F12 : Lock/Unlock.